




COOLEDGE

COOLEDGE TILE EXTERIOR FIT KIT USER GUIDE

The TILE Exterior Fit Kit can be used to address unexpected obstacles encountered on-site.



For detailed instructions, please refer to the EXT-0054 TILE Exterior Installation Manual



EN 60598 Compliant (as a system)



RoHS

IP65



5 Year Limited Warranty:
Parts and workmanship.



Cooledge Lighting Inc.
120-13551 Commerce Parkway
Richmond, BC V6V 2L1 Canada

O +1 604 273 2665
F +1 604 273 2660
T +1 844 455 4448
W cooledgelighting.com


Cooledge Lighting reserves the right to change materials or modify the design of its product without notification as part of the company's continuing product improvement program.

EXT-0056-R00-280617 1/3


EXAMPLE 1




1 Choose best arrangement of TILE Exterior Fit segments for the obstacle.





2 Snap first Fit segment and TILE together.



3 Mount first TILE and Fit segment to surface.




4 Cap unused connectors.




Repeat steps 2 & 3 for all TILE Exterior Fit segments

EXAMPLE 2


Site Drawing




Actual Site Condition




- 1 Choose best arrangement of TILE Exterior Fit segments for the obstacle.




- 2 Snap first Fit segment and TILE together.



- 3 Mount first TILE and Fit segment to surface.



- 4 Cap unused connectors.



Repeat steps 2 & 3 for all TILE Exterior Fit segments